


Checking the Tester

Press button (1). The LED (2) should flash green then go off. This indicates the tester is working and the battery is ok.

If the LED doesn't come on then it is time to change the battery - remove the 4 screws on the back to gain access.



Testing your Earthing Product

Connect your Earthing product to Earth.

Snap another connection cord onto the tester (3) and connect to the same Earth.

Most Earth Connection Plugs have 2 holes which will allow both connections. With some connection plugs or with a grounding rod kit, you may need to use the 2-to-1 splitter provided.

Press the metal disc on the back of the tester onto the Earthing product: onto the silver lines on a sheet, the top surface of a mat, or the inside of a grounding band.

The metal disc needs to be pressed firmly to the product to perform the test. Press and hold the button (1). The LED (2) should light green and stay lit while there is contact. This indicates everything is conducting correctly.

If you get no result at first, try different areas of the product. Also try a different connection cord if you have one.

